

CHANGING THE AA MENU PROMPT
(2ND PART OF GREETING)

Press: Feature 983

Enter: 120000 or 1020000

Press: OK

Display Shows: ADMIN
Mbox AA CCR

Press: AA

Display Shows: AUTO ATDT ADMIN

Press: GREETING (Grtg)

Display Shows: GREETING ADMIN

Press: AA

Display Shows: RETURN TO AA: Y

Press: NEXT

Display Shows: AA MENU PROMPT: N

Press: CHANGE (Chng)

Display Shows: PROMPT: PRIMEW

Press: PLAY to listen to greeting

Press: REC to record new greeting

Press: OK to end recording

Press: PLAY to listen to recording

Press: OK to accept

Press: RLS to end session