

CHANGING THE NUMBER OF RINGS BEFORE VOICE MAIL ANSWERS

Press: Feature 983

Password: 1020000 (3 digit extension number)
120000 (2 digit extension number)

Display Shows: ADMIN
Mailbox AA CCR

Press: AA
Display Shows: AUTO ATDT ADMIN
Grtg Table Lines

Press: LINES
Display Shows: LINE NUMBER
Retry Ok

Press: LINE NUMBER (eg. 001, 002, 003, 004) etc.
Display Shows: LINE: 1 ANS: Y
Chng Table Next

Press: TABLE
Display Shows: LINE: 1 TABLE: 1
Chng Rings Next

Press: RINGS
Display Shows: LINE: 1 RINGS: 4
Chng Ans Next

Press: CHANGE
Display Shows: NO. of RINGS
Retry Ok

Enter: Number of rings you want before voicemail answers

Press: OK

Press: * to return to AUTO ATDT ADMIN

Repeat steps 4 – 11 for all lines and press RLS to end session

