

TO ADD FILTERS

- Press: Feature **266344

- Password: 266344

Display Shows: CONFIGURATION

- Press: NEXT to General Admin

- Press: SHOW

Display Shows: SYS SPEED DIAL

- Press: NEXT to Capabilities

- Press: SHOW

Display Shows: DIALING FILTERS

- Press: NEXT to Set Abilities

- Press: SHOW

Display Shows: SHOW SET (enter the extension number that you wish to check or change the filter assigned)

Display Shows: SET FILTER: 00/01/02

NOTE - Filter 00 has no restrictions, 01 has all restrictions, 02 has limited or no restrictions.

- Press: CHANGE (enter in a filter to be assigned to that extension)

- Press: RLS